




KESTREL ASSEMBLY


TOOLS

We recommend you source and prep your tools before heading to your site. In addition, be sure to have hard hats and first aid materials on hand.




Assemble the Door Frame

1. Locate the four (4) pieces for the frame:
 - 1x Header - curved with rafter brackets on top
 - 1x Footer - curved without rafter brackets
 - 2x Vertical sections
2. Assemble door frame with provided screws using 1x "L" bracket at each corner. Nuts should go outside of frame.
3. Stand door frame upright.




Attaching the Lattice

1. Lay lattice on the ground. Each person should grasp one side of the lattice wall and move outwards, elongating the lattice until it measures 5'5" from top to bottom.
2. With each person grasping the lattice about one-third of the way in, stand the lattice upright.




3. Attach one end of lattice to door frame where it connects to an aluminum "L" bracket at the door. The brackets will line up with the X's on the end of the lattice.




Use the smaller white zip-ties to attach the door frame.

4. Take the tension strap and insert in between each "X" along the top of the lattice.



Secure the band as shown with the cam buckle, and tension from where the strap changes from white to black.



Attaching the Rafters


1. Using the provided cleaves pins, insert one (1) pin into each rafter in the lower hole.

Select three (3) rafters, and insert each about one-third of the way around the ring. Secure these rafters with your remaining pins by inserting the pin into the upper hole, locking rafters in position.

2. One person will now lift the ring into position, while a second person will secure the rafters into position with larger black zip ties. Each zip tie will go through the bottom hole on the rafter, over the tension band, and then under the “X” on the lattice.

3. The first three rafters need to have the same number of open spaces between at the top as V-joint spacing at the bottom (i.e. if you have 26 rafters, you will have 26 V-joints at the top of your lattice).

4. Add remaining rafters to the side of each of the first rafters and work your way around the yurt, adding one rafter at a time per section, slowly filling each section simultaneously.



Covering the Yurt

1. Drape cover over one half of the yurt. The cover is currently folded in half, like a taco.

2. Unzip the yurt door, and carefully unfurl the cover over the top of the yurt. Using a long handle or pole to push the fabric from underneath can be helpful.

Be careful not to tug too hard on the fabric, it should slide over the frame easily. Once the fabric is covering the yurt, align the fabric door and door frame by rotating the fabric with short, quick tugs.

3. Lift the dome into place from the outside of the yurt and secure it with the supplied bungee cords. One hook will secure to the attached anchor on the dome, the other will loop under the ring. You can adjust the length of the bungees by pushing the cord through the hook and tying a new knot.

